当 88597.88598 或 88599 记录器处于记录模式时如何打开 LCD?

在记录模式下，LCD 会关闭以节省电量。

要打开 LCD，只需按一次" MAX / MIN"键即可打开 LCD，无需长按。再按一次，LCD 将关闭，但仍保留记录。

How to turn on LCD while my 88597, 88598 or 88599 datalogger is in logging mode ?

Answer:
  The LCD is off during logging mode for power saving. To turn LCD on, just press "MAX/MIN" key once to turn the LCD on, no need to press long. Press again, the LCD will be turned off but the recording remains.