

## 如何设置 8808 的蜂鸣器报警？

警报设置将会同步蜂鸣器警报，如果用户在超出警报范围时未听到音频警报，则可能是电源不足。

请更换新电池或使用 9V 适配器充满电。

### Question

8808 user manual does not include the steps to configure the speaker when the alarm is adjusted, would you please advise?

### Reply:

The alarm setting will also synchronize the buzzer alarm, if user didn't hear the audio alarm when it's exceed the alarm range, the reason might be the power supply isn't sufficient. Please change new battery or use 9V adaptor for full power supply.