

7722 CO2 监测器上的继电器如何工作？

7722 CO2 中内置的继电器很小，只能驱动小型设备。

7722 继电器的规格为 1A 30VDC / 0.5A 125VAC，供您参考。

要在更大的货车或通风系统上行驶，它们之间必须有另一个更大的继电器来控制电源的开/关。

Question

How's the relay on #7722 CO2 monitor work?

Reply:

The relay build in #7722 CO2 is quite small, it can only drive a small device. The specification of #7722 relay is 1A 30VDC/0.5A 125VAC for your reference.

To drive on a bigger van or ventilation system, it must have another bigger relay in between to control power on/off.